


МИКСЕР STARFOOD DM-C1



МИКСЕР STARFOOD DM-C1

1	Motor cover
2	Silicone washer
3	Motor housing
4	Motor
5	Power switch
6	M6 Screw nut
7	Washer
8	Front housing
9	Support plate
10	Micro switch
11	Rear cover
12	Base
13	Power cord head
14	Power cord
15	Metal base
16	Feet
17	Cup
18	Screw
19	Rotor Blades
20	D8 tube
21	Cup holder cover
22	Base board