



Pos	Code	Description
0001	70146	BIG HOPPER LID
0002	70145	HOPPER SHUTTER
0003	90166	BIG HOPPER WITH SHUTTER
0004	50381	DISPLAY BOARD
0005	50382	SERIAL CONNECTOR
0006	70272	SPOUT SUPPORT
0007	70271	CARTER
0008	40239	SPOUT
0009	20346	HOOK
0010	70345	FILTER-HOLDER REST
0011	70335	TRAY
0012	85198	SERIGRAPHY
0013	70334	RING COVER
0014	40284	SETTING RING
0015	90406	SUPPORT ASSEMBLY
0016	45124	LMKAS WASHER
0017	70286	RING
0018	912086	SCREW
0019	90301	BURRS
0020	45132	NUT
0021	746822	WASHER
0022	10257	DRIVE HUB
0023	93120	MOTOR
0024	50192	CAPACITOR
0025	20483	BRACKET
0026	50380	ELECTRONIC BOARD
0027	75210	PIN
0028	50138	BUTTON
0029	50170	SWITCH
0030	50137	SUPPORT
0031	50358	WIRING
0032	80128	BOX
0033	12401	GRINDER BODY
0034	45529	FLAP
0035	70198	COVER
0036	70331	PLATE
0037	50161	CORD CLAMP
0038	70140	FOOT
0039	50207	CORD