




ELECTRIC SOLID TOP

Pos	Code	Description
0001	CR0689310	COOKING PLATE [C] SOLID TOPS ELECTRIC RANGE S90
0002	MACM294000	SPRING [C] RADIANT ELEMENT - min. 10 pcs or multiples
0003	MA2582900	UPPER PIN [C] DOOR PROFILE
0005	CR0841170	THERMAL SWITCH [C] - min. 10 pcs or multiples
0006	MA1037100400	3 POLES TERMINAL BLOCK [C]
0007	MACM303000	FAN [C]
0008	CR0732010	FAN SUPPORT [C] NCT9
0010	CR1095270	KITCHEN LABEL TP.ANT.SILKO E15 [C]
0011	CR0581190	BUSH [C]
0012	CR1095040	KNOB [C] SHAFT E15 D. 6
0013	CR1095280	PLACCA SERIG. CUCINA TUTTAP. POST.SILKO
0014	CR0588510	GASKET [C] CONTROL PANEL 900
0015	CR0588950	EXTENSION [C] DRAIN PASTA COOKER 900
0016	CR0587500	ORANGE PILOT LAMP [C] Ø13,5MM 230V
0017	CR0682520	RED PILOT LAMP [C]
0018	CR0587650	GASKET [C] SHAFT
0019	MA1037313200	SELECTOR SWITCH 250V 6A
0019	MA710300	COMMUTATOR 0-1 [C] POSITION
0020	MA1988500	HANGER [C]
0021	CR0734520	THERMOSTAT [C] 50-450°C
0022	CR0688660	SQUARED ELECTRIC PLATE [C] 4KW 300X300
0022	CR0735670	ELECTRIC PLATE [C] 3,5KW 300X300 SQUARED
0023	CR0681750R	PIPE [C] D. 30X70CM
0024	MA1033504000	CLAMP [C]
0025	CR1166940	FLUE GRID [C] M60 ESSENCE 2015