


Apach

CHEF *Line*



ELECTRIC FRYER 15lt.

Pos	Code	Description
0001	MA1031110222	BASKET [C]
0002	MACM229101	COVER [C] FRYER 10L
0003	MACM073100	HANDLE [C] MT/105
0004	MACM012401	NUT [C] M10X1
0005	MACM097900	GASKET OR [C] THERMOSTAT BULB- min. 10 pcs or multiples
0006	MA1033515800	ELASTIC COUPLER [C]
0007	MACM216101	LIFTING DEVICE [C] HEATING ELEMENT FRYER 10L
0008	CR1161830	UNIVERSAL PC BOARD [C]
0009	CR1161821	INTERFACCIA TOUCH ELETTRONICA SILKO 2021
0010	CR1161100	ENCODER [C]
0011	CR1097880	GLASS [C] SILKO FOR KNOB
0020	CR1094330	KNOB [C] SHAFT D. 6
0021	CR0581190	BUSH [C]
0022	CR0587530	METAL LABEL [C]
0024	CR0588950	EXTENSION [C] DRAIN PASTA COOKER 900
0025	CR0688420	CRUSCOTTO FRIGG.10L.ELE.900 M60
0026	CR0582140	OR SEAL
0027	CR0589660	THERMOSTAT [C]
0028	MA1037112400	CABLE CLAMP
0029	MA1037114500	JAM NUT OBO 116/PG21 NY
0030	MA1878400	TERMINAL BLOCK [C]
0031	MA1590800	EXTENSION [C] DRAIN
0032	CR1342950	OR SEAL
0033	MA1450500	DRAIN TAP [C]
0034	CR0585490R	ASS.FIANCO DX TOP 900 (RIC)
0034	CR0585500	LEFT SIDE PANEL [C] TOP 900