




ELECTRIC FRYER 15lt.

Pos	Code	Description
0001	CR0686180	BASKET [C] FRYER 700
0002	MACM073100	HANDLE [C] MT/105
0003	CR0686210R	FRYER COVER [C] 15L.900
0004	CR0508560	SHELF GRID [C] FRYER FQG 41/61
0005	MA15119299	DOWEL M5X8 UNI 5927- min. 10 pcs or multiples
0006	MACM021600	RING NUT FRYER
0007	MA1037111300	MICROSWITCH [C]
0008	CR1161830	UNIVERSAL PC BOARD [C]
0009	CR1097880	GLASS [C] SILKO FOR KNOB
0010	CR1161100	ENCODER [C]
0011	CR1161821	INTERFACCIA TOUCH ELETTRONICA SILKO 2021
0020	CR0585850	EXTENSION [C] DRAIN FRYERS 23L
0021	CR0733340	VALVE [C]
0022	MA1878400	TERMINAL BLOCK [C]
0024	MA6086113	FOOT 1 3/4 INOX FLANG.H150
0025	CR0582130	NUT FOR BUSHING PASTA COOKERS
0026	CR0582140	OR SEAL
0027	CR0582120	HEATING ELEMENT BUSH [C] FOR PASTA COOKERS
0028	CR0583860R	HEATING ELEMENT [C] 230V FRYER 15L
0029	MA1033515800	ELASTIC COUPLER [C]
0030	MACM012401	NUT [C] M10X1
0031	MACM097900	GASKET OR [C] THERMOSTAT BULB- min. 10 pcs or multiples
0032	CR1342950	OR SEAL
0033	MACM200100	GREASE [C]
0034	CR0689390	LIFTING DEVICE [C] HEATING ELEMENT FRYER 15L