



parts.code	parts.number	parts.name
GM2486420	02	CARCASSA ALLUMINIO WIFOOD 135
GM5036100	04	MOTOR SOFTCOOKER Y09
IX21481001.5008	05	SPRING PIN DIN 1481 1,5X8
GM5256600	06	HEATING ELEMENT 2000W_ SOFTCOOKER 09
IX2125005	07	WASHER DIN 125 D 5
GM5946390	08	PCB WI-FOOD WI-FI
GM2483380	09	FALSOFONDO WIFOOD Y20
GM2492150	10	DISPLAY ASSEMBLY WIFOOD WI-FI
GM5826100	12	THERMOSTAT PROBE FOR SOFTCOOKER 09
IX2934006	13	HEX.NUT DIN 934 M 6
GM5826150	14	SAFETY PROBE 10K FOR SOFTCOOKER 09
IX27985005010	15	PAN HEAD SCREW DIN 7985 M5X10
GM3047350	16	ALUMIUM BASKET WIFOOD 135
GM5036850	18	MOTOR FAN _ SOFTCOOKER Y09
GM5036870	20	SPOKED IMPELLER SOFTCOOKER 09
IX2933003006	21	HEX.SCREW DIN 933 M 3X06
GM4253680	22	THERMAL BREAK WIFOOD 135
IX26798A003	23	SERRATED WASHER DIN 6798- A D 3E
GM5826070	24	PIASTRA FERMA MOTORE WI- FOOD

parts.code	parts.number	parts.name
GM2486170	25	BUSHING _ SOFTCOOKER Y09
IX2914003004	27	HEADLESS SCREW DIN 914 M3X4 P.CN
GM5826125	28	WATER LEVEL SENSOR WI- FOOD
IX2934004	29	HEX.NUT DIN 934 M 4
GM2486280	30	PROBE BUSHING _ WI-FOOD
GM2486290	32	PROBE WASHER _ WI-FOOD
IX2912003040	33	HEX SOCKET HD CAP SCREW DIN 912 M3X40
GM5846050	34	FUSE HOLDER P4036 15A 250V_ SOFTCOOKER
GM5846055	36	FUSE 6,3X32 12,5 A SOFTCOOKER Y09
19410102	38	ON/OFF SWITCH COMELUX 401/L
GM5036875	40	LOWER FAN, SOFTCOOKER
GM2023195	46	BUSSOLA TIRANTE FISSAGGIO WIFOOD
19562504	50	TIE ROD KNOB M8 5
19563232	52	BUFFER PIN D8,5XHT3,2 _ MIRRA 300
GM5826065	53	PIASTRA MOTORE WIFOOD Y20
GM2023190	54	TIE ROD WIFOOD
GM4296235	56	BRASS SPACER MM 8X16 _ SOFTCOOKER
GM2492260	57+58 NR	PAIR OF BLACK ABS SIDES WI- FOOD
IX279813.9019	59	SELF-TAPPING SCREW DIN 7981 D 3,9X19
GM5506360	60	CABLE 3X1,5 SCHUKO 3M WI- FOOD
GM5893090	61	STRAIN RELIEF 1546.11.10 PG11 BLACK